

SUPER CHEXXTM



OWNERS AND SERVICE MANUAL
INNOVATIVE CONCEPTS IN ENTERTAINMENT INC.

TABLE OF CONTENTS

SUPER CHEXX™ Game Play.....	Page 4
Outstanding Features.....	Page 5 & 6
Programming.....	Page 7
Game Assembly.....	Page 8 & 9
Game Operation—Test.....	Page 8
Major Assemblies Terminology.....	Page 10
Maintenance.....	Page 11 THRU 13
Troubleshooting and Repair.....	Page 14 THRU 18
Parts Listing.....	Page 19
Previous boards and sensors.....	Page 20 THRU 21
Scoreboard Assembly.....	Page 22
Cabinet & Dome Assembly.....	Page 23-25
Schematics & Wiring Diagrams.....	Page 26 THRU 32

SUPER CHEXX™ GAME PLAY

The SUPER CHEXX™ Hockey game has been designed to resemble “real” hockey action. The object of the game is to out-score your opponent before time runs out. Goals can be scored, with the game continuing, until the “last puck in play” mode begins. When the last puck in play is scored, the game ends.*

Example: If a score is 5-3, the last puck would result in a final score of 5-4 or 6-3.

*The exception to this rule occurs when a final puck would create a tie score.

Example: If the score is 2-1, the last puck might make the score 2-2. The game then automatically goes into a “Sudden Death Overtime” mode and a final tie-breaking puck is ejected. The game will end when the tie-breaking goal is scored.

The National Anthem, as well as the “Boo” sound and the “Ooh’s” and “Aah’s” add to the excitement of playing SUPER CHEXX™. The “Boo” button can be used to eliminate the National Anthem or to “Boo” your opponent.



FEATURES

SUPER CHEXX™ is a unique kinetic action hockey game, using state-of-the-art components, electronics, and advanced sound effects designed to closely resemble the action, play, and feel of a real ice hockey game.

BREAK RESISTANT POLYCARBONATE DOME

The cover of this game is made of Lexan and will resist breaking or cracking.

OVERHEAD SCOREBOARD (341X)

Scores and shots on goal are automatically tabulated by the main processor unit and displayed here. Other features include a running time clock, digital period display, and a fluorescent light that produces minimal heat eliminating the need for a fan.

UNIQUE SOUND EFFECTS

The sound effects in this game use state-of-the-art components. Along with synthesized organ chants, this game utilizes natural sounds actually recorded at a real hockey game. Cheers can be noted when a goal is scored. "Oh" sounds are produced when a puck enters the goalie's crease. Organ chants indicate period changes, last puck in play mode, and sudden death overtime. A player can actually "Boo" his opponent by pressing the "Boo" button located at each end of the cabinet. Added to all these sounds are a full-time background noise and a National Anthem at the beginning of each game. A player can even bypass the anthem if desired by pressing the "Boo" button.

GEAR / CLUTCH DESIGN (3012X)

Each player on the game rotates on a 2.4:1 gear mechanism, which utilizes a built-in clutch to allow opposing players to strike or check one another without causing damage to components. This feature also eliminates intentional abuse. The gearing mechanism has been designed to allow a player to rotate at maximum speed with a minimum of effort.



CENTER ICE FACE OFF

This hockey game has a center ice face-off feature to add to the realism of play. The puck is automatically ejected once at the beginning of the game and once after each goal. The puck may be ejected manually by pressing the Boo/Eject buttons.

NEW ROD MATERIAL

Unlike previous games using rods that bend or break easily, SUPER CHEXX™ uses rods with a specially developed fiberglass composite and exterior coating to eliminate previous problems. These rods are immune to even torturous abuse. They can bend almost 90 degrees and still return straight time after time.


PLAYERS



LONG STICK PLAYER - 1 PER TEAM (7007B pictured)



SHORT STICK PLAYER - 4 PER TEAM (7010B pictured)



GOALIE - 1 PER TEAM
(7001X includes block assembly)

FEATURES

SUPER CHEXX™ has realistic three-dimensional decorated players to even further enhance realism and enjoyment of the game.

GAME CABINET

The cabinet is of unitized construction using high quality aluminum for strength, durability, and reliability. Threaded inserts are used throughout the cabinet to make removal and installation of parts in the cabinet fast and easy.

GAME BASE

The base design is a first in the game industry, using a one-piece high impact plastic material versus conventional wood or particleboard cabinetry. It is impervious to liquid spills as well as many other typical abuses to which games are subjected. The coloring has been molded into and throughout the base, eliminating the effect of scratches that harm the appearance and beauty of the game.

ADJUSTABLE TIME AND VEND PRICE

The time and vend price of the game can be adjusted individually by switches on the main PC board. Time can be set for two, three, four, or five minutes. The vend price can be adjusted for \$.25, \$.50, \$.75 or Free Play. Any combination of time and price can be used.

ELECTRONICS ACCESS

All of the SUPER CHEXX™ electronics are located on a single PC board just inside the coin door. All IC's are readily accessible and mounted in high quality sockets simplifying repairs.

SCOREBOARD ELECTRONICS

The scoreboard electronics, designed with state-of-the-art circuitry, are very reliable. If any repair should be necessary, the scoreboard can be replaced in less than (5) minutes, eliminating costly down time.

SPEED OF PLAY


The play of the game is extremely fast. A unique ramp construction eliminates dead spots and a special finish on the highly polished playfield enhances the puck action. The gearing ratio (described earlier), used for fast and effortless play and rotation, provides for greater speed and accuracy when shooting the puck.

QUICK ASSEMBLY

The game, designed in two pieces with an upper and a lower half, can be assembled and connected in less than (5) minutes.

OVER / UNDER COIN DOOR

An industry standard over / under coin door is used in the SUPER CHEXX™ game.




PROGRAMMING INSTRUCTIONS

- PRESS THE PROGRAM (PGM) BUTTON OF THE MAIN P.C. BOARD. (THIS IS THE LEFTMOST OF THE 4 BUTTONS).
 - PRESS THE SELECT (SEL) BUTTON TO ADVANCE THROUGH THE VARIOUS PROGRAMMING OPTIONS.
 - PRESS THE STEP (STEP) BUTTON TO CHANGE THE VALUE OF THAT PARTICULAR PROGRAMMING OPTION.
 - WHEN FINISHED, PRESS THE PROGRAM (PGM) BUTTON TO RETURN TO GAME PLAY MODE.
- NOTE: PRESSING THE START BUTTON WILL PLAY 1 GAME WITHOUT ADVANCING ANY COUNTERS. (OR DISPENSING ANY TICKETS FROM THE OPTIONAL TICKET DISPENSER)

GAME OPTIONS

- COIN 1 (COINS PER CREDIT)** SET THIS VALUE FOR HOW MANY COINS IT WILL TAKE FOR 1 CREDIT.
- COIN 2 (COIN 1 EQUIVALENT)** SET THIS VALUE TO 1 IF YOU WISH THE VALUE TO BE THE SAME AS COIN 1 (IF YOU WISH THE VALUE TO BE TWICE AS HIGH, SET TO 2. IF YOU WISH THE VALUE TO BE THREE TIMES AS HIGH, SET TO 3, ETC...).
- TIME UNITS PER PERIOD** SET THIS VALUE TO 20 FOR HOCKEY, OR 15 OR 30 FOR SOCCER.
- TIME PER PERIOD** SET THIS NUMBER FOR THE ACTUAL AMOUNT OF SECONDS PER PERIOD. MULTIPLY THE NUMBER OF PERIODS BY THE NUMBER OF SECONDS YOU CHOOSE FOR OVERALL GAME TIME. EXAMPLE: 60 SECONDS X 3 PERIODS (HOCKEY) - 3 MINUTE GAMES.
- NUMBER OF PERIODS** SET THIS NUMBER TO 3 FOR HOCKEY, OR 2 OR 4 FOR SOCCER.
- ANTHEM** SET THIS VALUE TO 1 FOR THE CANADIAN ANTHEM, OR 0 FOR THE U.S.A. ANTHEM.
- AWARDS PER GAME** SET THIS VALUE FOR THE NUMBER OF TICKETS YOU WANT DISPENSED AT THE END OF THE GAME.
- ATTRACT MODE INTERVAL** SET THIS NUMBER FOR THE AMOUNT OF TIME BETWEEN ATTRACT MODE SOUNDS. SELECTING 0 WILL TURN THE ATTRACT MODE OFF.
- PUCK EJECT STRENGTH** ADJUSTABLE FROM 5 TO 15. DEFAULT IS 10.



GAME ASSEMBLY

These steps should be followed for initial installation as well as any time the game is dismantled and moved to a new location.

INSPECT INSIDE OF BASE

1. Check for loose parts or foreign material in bottom.

Inspect harnessing to speakers, coin door and coin meter.

Inspect main PC Board for damage and familiarize yourself with the 15-pin cabinet harness connector and the 8-pin header for the scoreboard ribbon cable.

2. Place cabinet on Base oriented with hinge side of cabinet opposite the coin door side of the Base.

Align the two so that the threaded cabinet mounting inserts are visible through the access holes and the mounting holes in the Base.

Install 4 Allen Head mounting bolts with fender washers and tighten with supplied T-handle wrench. Install the first bolt and tighten slightly. The remaining bolts may now be installed. The cabinet may have to be shifted so that the holes in the Base line up with the threaded inserts in the cabinet. Tighten all bolts securely.

3. Connect 15-Pin Connector and Ribbon Cable connector to main PC Board. **The locking edge of the ribbon cable connector should face the rear of the base. Do not force or connect backwards or damage will occur.**

Connect the loose ground wire to the open ground terminal on the top of the cash box.

4. Plug game into 110 (optional 220) volt GROUNDED AC outlet and turn on PC Board mounted power switch.

Warning: Failure to use a 3-prong grounded outlet will void your warranty and may cause harm to the game, yourself, and others.

5. Coin-up game and check for proper operation.

6. Finally, make sure your game is clean. A clean game looks good, gets more play, and makes more money than a dirty game.

SEE PICTURE OF WIRING ON FOLLOWING PAGE.

GAME OPERATION - TEST

IMPORTANT: IF THE GAME FAILS TO PERFORM THE FOLLOWING TESTS AS DESCRIBED, REFER TO THE TROUBLESHOOTING SECTION.


1. Before starting a game, check to see that all players rotate smoothly and that all rods move in and out freely.

NOTE: THE GEAR BOXES REQUIRE 10 - 20 GAMES TO FULLY BREAK IN. SLIGHT RESISTANCE WHEN ROTATING THE PLAYERS ON A NEW GAME IS NORMAL.

2. Insert the proper number of coins to start game. The National Anthem will begin and upon completion, the puck will eject from the ejector chute. Shoot the puck in each net several times to ensure proper operation of the ejector.
3. Each time the puck enters the net; the score indicators on both sides of the scoreboard should indicate the goal scored. Continue scoring until the game ends, checking the score indicators for proper operation. Check to see that the score

indicators on both sides of the scoreboard are working correctly.

4. Restart the game. Press the Boo/Eject button to ensure the National Anthem is bypassed. The puck should eject.
5. After the puck ejects, press the Boo/Eject buttons on both ends of the game to ensure the "Boo" sound is heard and eject Solenoid is activated.
6. Run the puck through each goal crease. The "Oh" sound should be heard as the puck passes through the crease. Note that a shot on a goal has been registered.



Super Chexx Major Assemblies Terminology



Scoreboard Assembly – displays scores, credits, and shots on goal. Not included in Dome Assembly.

Dome Assembly – comes with ribbon cable (specify new or old style cable)

Cabinet Assembly – Contains mechanical assemblies, wiring and sensors.

Base Assembly – Contains speakers, main board, coin door (top door) and cash box door (lower door) assembly.

SC2070X – Main Board 4th Generation with Sound daughter board.

Ribbon Cable Connection. NOTE POSITION OF RED STRIPED WIRE

Volume Knob

AC Voltage Adjust switch (115/220)

On/Off Switch

Fuse Holder - 1 Amp Slow Blow Fuse


Base harnessing (part number 279X)

Cabinet harnessing (part number 278X)

Programming Buttons

Coin Counter

Base Main Ground



MAINTENANCE

All parts in the SUPER CHEXX™ Hockey Game have been manufactured to the highest standards possible. The following maintenance should be performed as recommended to assure optimal performance and longevity of the game.

WARNING: THIS GAME DOES NOT REQUIRE ANY LUBRICATION. USE OF ANY OILS OR GREASE MAY VOID YOUR WARRANTY.

Most mechanical maintenance jobs, when required, will necessitate removal of the dome and / or ice surface. In all cases, when the ice surface must be removed, follow the ice surface removal procedure as given.

PARTS KIT

Included in the spare parts kit, is a wire cable with loop & hooks. This is used to hold the dome open when tilted back to service the game.


In the event the goalies are removed, extra cotter pins are provided if the original cotter pins are damaged or lost.

PUCK

Inspect the puck for large gashes, which may impede a smooth rolling action down the puck ramps. Replace if necessary.

PUCK RAMPS

Periodically check the puck ramps for dirt accumulation and / or other objects or materials that may cause the puck action to slow down. To clean the ramps, remove the goalies. Slide all players to center ice (this saves time, as all the players and ice surface do not have to be removed). Bend up the ice on either end and remove the nets. Clean out the tracks and reassemble.



SCOREBOARD LIGHTS

Replacement is advised when necessary. Remove the four screws on the light diffuser and pull out the bulb. Insert the new bulb and reassemble.

NOTE: TIE WRAPS HAVE BEEN USED TO SECURE THE FLOURESCENT LIGHT AGAINST SHIPPING DAMAGE AND ABUSE ON LOCATION. IT IS RECOMMENDED THAT THESE BE REPLACED AFTER A NEW LIGHT IS INSTALLED.



COIN MECHANISMS

Mechanisms should be cleaned and adjusted when necessary. Follow the manufacturer's instructions on adjustment and maintenance.


PLAYER WASHERS

These washers, located over each gearbox, serve to keep the players shafts in place in their gearboxes.

Extreme care should be exercised when pulling out or pushing in players because a washer that falls into a track can be bothersome to remove. To help eliminate this problem, push all the rods all the way in, and pull the player straight out. When pushing a player back in, be sure the gearbox is lined up with the shafts. If not, slowly rotate the rod while pushing down on the player.



MAINTENANCE



NOTE: WASHERS SHOULD BE REPLACED WHEN WORN TO THE POINT THAT THEY CAN NO LONGER HOLD THE PLAYERS IN. AFTER PLAYERS ARE INSERTED, PULL UP GENTLY TO TEST THE STRENGTH OF THE WASHERS.

SOUND EFFECTS

Periodically test the sound effects, sensors, and the "Boo" button to ensure the proper functions. Test for National Anthem bypass.

ICE SURFACE

The ice surface should be cleaned as needed, using Windex™, Fantastic™, or a comparable product. Apply liberally to a lint-free cloth, wipe surface thoroughly, and let dry. For a "faster" ice surface, dust lightly with Pledge™ and let dry.

DOME

The Lexan dome should be cleaned as needed, using a furniture polish type of cleaner. Apply to a lint-free cloth and wipe dome thoroughly.

NOTE: PLEDGE™ IS RECOMMENDED. ALWAYS TEST THE CLEANER YOU INTEND TO USE ALONG THE FLANGE TO MAKE SURE THE CLEANER WILL NOT HARM THE DOME FINISH. TO REMOVE SCRATCHES, A SPECIAL SCRATCH REMOVER FORMULATED FOR LEXAN SHOULD BE OBTAINED.

PLAYERS

Periodically inspect the players for appearance or possible damage. Replace when necessary.

EJECTOR MECHANISM



Periodically test the mechanism by scoring goal and observing puck ejection. If puck fails to eject, does not clear ice surface, the mechanism is not working correctly. Open the dome and remove the ice surface.

**NOTE:
BE CAREFUL NOT TO LOSE THE FLAT WASHERS.**

Start the game and observe operation. Check for foreign particles under the ejector arm. The entire bracket assembly can be repositioned to correct improper ejection in any direction. Loosen the 2 mounting screws and re-position as necessary. Be sure all parts work freely.

Check by pushing the solenoid plunger only, to see that the ejector lifts up about 3/8" from the cabinet bottom. If less movement is noted, be sure that the ejector is not hitting any of the side chute areas or has become bent through failure of another part.


Excessive random angle ejections can be eliminated by centering the ejector in the vertical area of the chute. (An improperly positioned ice surface may also cause angled ejections) An ejector that sticks in the up or down position is due to either improper positioning, a broken spring or a damaged solenoid.



MAINTENANCE

GEARBOXES


Gearboxes should be inspected periodically to ensure smooth operation. Gearbox tracks should be kept as clean as possible. If a gearbox seems to rotate stiffly, first check to see that a rod collar is not pushed up tightly against it (this can happen if a grip comes off a rod and a gearbox hits a solid object, usually on defensemen). Back off a collar from a gearbox by loosening, moving, and retightening.



NOTE GEARBOXES ARE LUBRICATED FOR LIFE AND SHOULD NOT BE OILED OR GREASED.


ROD BEARINGS

Check once a year for excessive wear. Replace when necessary.




PUCK CHUTE

Clean periodically to ensure a good sliding surface. Check for cracks. Small cracks can be glued with a C/A adhesive. Large cracks require changing the part.



GOALIE MECHANISMS

Check for smooth operation.



RODS

Check periodically for cracks and gouges. Replace if necessary. Clean Mineral Spirits or Paint Thinner. Do not allow cleaner to contact the Dome, as it will damage the Dome.

TRACKS

Check periodically. Clean by pushing a rag along the length of the track.

SENSORS


These should be tested periodically by moving the puck over the "Oh" sensors and through the score sensors. Test a suspect sensor by unplugging and testing with ohmmeter. Replace if necessary.

TROUBLESHOOTING AND REPAIR

PUCK WILL NOT EJECT

For some ejection problems the ice surface may have to be removed.

1. Opening the dome and sliding all of the players to the center ice can correct dirt in the puck ramps. Next, remove the goalies one at a time, bend up the ice surface and clean the ramps. Assemble in the reverse order.
2. It is possible that the software (option #9) has been set up with the solenoid strength set too low. Enter the programming mode, go to option #9 and check the setting. The higher the value, the higher the puck will eject. Adjust the eject strength as necessary.




3. A puck ramp may become pushed up during shipping or moving. Just push it back down in the retainer/chute with a pencil or screwdriver.
4. A unique electronic circuit incorporated on the main PC Board prevents the eject solenoid from burning out. If a solenoid problem is suspected, check for a pulse of about 12 volts at the solenoid. Then remove the wires to the solenoid and check that the coil is not open or shorted. A good solenoid will read between 3-4 ohms.


NOTE: REPLACE THE SOLENOID ONLY AFTER DETERMINING WITH AN OHM/VOLT METER THAT THE SOLENOID WAS RECEIVING POWER.

PUCK TAKES TWO OR THREE TIMES TO EJECT

1. A puck hitting the ice surface can be corrected by first making sure the ice surface is in place. If it is in place, observe which way the playfield is positioned. The opening can be centered by either bending the pins that locate the nets and ice surface from goal to goal, or bending the puck return chutes underneath for side-to-side adjustment.



2. To determine if the ejector is misaligned, first remove the ice surface and then start the game. Look straight down the ejector chute and observe how the puck ejects. If the puck consistently hits one side of the chute, the ejector should be adjusted. Loosen the 2 screws that mount the solenoid assembly to the cabinet. Re-position the assembly so that the cup where the puck sits is centered into the vertical area of the chute.



TROUBLESHOOTING AND REPAIR

GEARBOX IS DIFFICULT TO TURN

1. A gearbox-coupling collar may have been forced against a gearbox causing uneven or difficult turning. The usual cause for this is a handle grip coming off a rod and allowing the gearbox to hit either another gearbox or a cabinet end. To repair, simply loosen the collar and back it away from the gearbox between 1/32" and 1/16". Retighten.
2. Gear teeth being stripped out will generally cause binding at certain points of rotation. This situation should not occur until many games have been played. However, to check for bad gears, first remove the gearbox from the game. Loosen the gearbox collar and slide out the gearbox. If teeth on gears are worn out, replace the gearbox.
3. A worn gear bearing can cause a gearbox to work improperly. If you suspect a gear problem, first remove the gearbox from the game. If no problems are visible, disassemble the gearbox. If a worn bearing is found, replace the gearbox.

GAME LIGHTING DIM

1. The scoreboard bulb may be burned out. Open the dome and see if the bulb appears to be burned out while the game is plugged in. Unplug the game. Remove the screws holding the right diffuser in place. Replace the light bulb and reassemble.
2. Very low AC power will cause poor lighting. To test, use a voltmeter on the suspect line to determine voltage. A CHEXX™ game hooked up to a line with too many other games may experience this difficulty. Move the game to its own AC line if this problem is experienced.


NO LIGHT IN GAME

1. The light bulb may be burned out. Open dome see if bulb is burned out. Replace if necessary.
2. A loose scoreboard connector is not likely to affect the bulb without affecting some other component in the scoreboard. However, make sure the connectors are firmly seated.

PLAYERS RUN INTO THE END OF THEIR SLOTS

1. A rod collar slipping may cause a player to hit the end of a slot in an ice surface. Open the game and rotate the rod until you can see the rod and gearbox touch, through the slot in the collar. If the rod and the gearbox do not touch, loosen the collar make sure the rod and gear box coupler touch, and retighten the gearbox. Be sure to leave 1/32" to 1/16" between the collar and the gearbox body.

PLAYER ROD & GEAR BOX SHAFT MUST MEET IN CENTER OF COLLAR SLOT



SCORE INDICATORS DO NOT WORK PROPERLY

1. A bad LED may cause malfunction. Replace the scoreboard and run electronic tests on the faulty unit.
2. A bad scoreboard chip may cause indicator malfunction. Replace the scoreboard and run electronic tests on the faulty unit.
3. A loose connection may cause malfunction. Check and repair as necessary.

GAME LOSES PLAY SEQUENCE, GIVES FALSE SCORE, WILL NOT START WHEN MONEY IS INSERTED

1. Although game is protected against static electricity, an unusually large shock will cause the microprocessor to lose sequence. To correct the problem, turn off power and turn it back on to reset electronics.
2. A game plugged into an ungrounded outlet has no protection from static electricity. A large enough shock may destroy the IC chips. Electronic tests may be run to determine the fault. Repair as necessary.

COINS NOT REGISTERED CORRECTLY

1. A bad micro-switch may be a problem due to internal failure. Test with an ohmmeter. Replace if necessary.
2. Loose connections may cause money to be registered improperly. Check the connectors from the coin mechanisms, as well as the connectors on the main PC Board. Repair if necessary.
3. A bad capacitor (CZ5) on the main PC Board may cause bounce problems with the micro-switch. Run electronics tests to determine the problem.

TROUBLESHOOTING AND REPAIR

NO "OH" SOUNDS OR REPEATED "OH" SOUNDS

1. Short or open circuits in the harness or one of the reed switches on the "Oh" sensors are the most common problems. Repair as necessary.
2. A bad IC chip on the main PC Board may cause problems. Run electronics tests. Repair defective components.

SCORE IS NOT REGISTERED-NO CHEER

1. A bad Reed Switch may cause a goal not to register. Disconnect and test with an ohmmeter. Replace if defective.
2. A bad connection could be a problem. Check associated harnessing and connectors with an ohmmeter.

SCORE IS NOT REGISTERED-GAME CHEERS

1. A scoreboard connector may be loose or bad. Repair or correct as necessary.
2. A bad scoreboard IC chip may be a problem. Replace the scoreboard and run electronics tests to determine the problem.

SCORE AND CHEERING KEEPS REPEATING FOR ONE TEAM WITH NO GOALS ACTUALLY BEING SCORED

1. A Reed Switch shorted to the cabinet will cause this problem. Usually an exposed wire touching the cabinet will be the cause of the problems.
2. A Reed Switch, always closed, can be tested by first disconnecting it from the board. Use an ohmmeter to see if the switch is always closed. If it is, replace the score Reed Switch.


SOUND GOES LOW OR GOES ON AND OFF

1. Check the audio IC chips on the main PC Board. Replace any defective parts.
2. A faulty volume control is a possible cause for intermittent sound. Rotating the volume control will usually show a problem. Many times, the problem can be corrected by cleaning with a commercially available switch cleaner.
3. A bad speaker connection to the main PC Board may be the problem. Check and repair as necessary.

PLAYERS RUB ON THE SIDES OF THEIR SLOTS

1. On rare occasions a track may become bent, forcing the player to work improperly. If, when the ice surface is properly located, you can see the top of an aluminum track, the track must be bent. Use a large screwdriver or other suitable object, and gently pry in the desired direction to obtain clearance. Check for smooth operation.


NOTE: BE SURE NOT TO GOUGE THE SIDE OF THE CHANNEL WHEN PRYING. A RAG SHOULD BE WRAPPED AROUND YOUR SCREWDRIVER.



NOTE: ALUMINUM TRACK IS NOT VISIBLE IN PHOTO.

TROUBLESHOOTING AND REPAIR

TOP CABINET ASSEMBLY WITH ICE SURFACE & PLAYERS INSTALLED




PLAYER NUMBERING AND LAYOUT

	<u>18 Long</u>		12 Short
	6 Short		<u>4 Short</u>
30 Goalie	<u>14 Short</u>	14 Short	<u>30 Goalie</u>
	4 Short		<u>6 Short</u>
	<u>12 Short</u>	18 Long	

TROUBLESHOOTING AND REPAIR

TOP CABINET ASSEMBLY WITH ICE SURFACE & PLAYERS REMOVED




PARTS LIST


745	DECAL (CABINET) (NEW STYLE)	3025X	ICE SURFACE ASSY.
1002X	ROD COLLAR (LONG)	3035	PLAYER ROD WASHERS
1003X	ROD COLLAR (SHORT)	3036	DOME WASHERS
1004X	GOALIE TRACK	4002	GOALIE BUMPER STOPS
1005	GOALIE SWING ARM	4003	CABINET GASKET PER PC. (10 FT.)
1007X	PLAYER TRACK 1 & 8 EACH	4004	COLLAR RUBBER
1008X	PLAYER TRACK 2 & 7 EACH	5003	SPEAKER GRILL
1009X	PLAYER TRACK 3 & 6 EACH	5101A	REJECT BUTTON
1010X	PLAYER TRACK 4 & 5 EACH	5105	EJECTOR ARM
1112	CTR. EJECT RETAINER CHUTE	5011	EJECT. SOLENOID SPRING
1013	PUCK RAMP ASSY.	6001	DOME FASTENER
1014	SCORE SENSOR BRACKET	6001B	3/16" DOME BOLT ALLEN WRENCH
1016	DOME HINGE	6006	1/4 - 3/8 SHOULDER BOLT
1018	GOALIE BEARING ASSY.	6010	GOAL. CLUTCH-O-RING
1019	CENTERMAN STOP	6011	GOAL. ROD WASHER
1120	EJECT SOLENOID BRACKET	6024	DEFENSEMAN STANDOFF BOLT
243X	DISPLAY PCBA	6025	VINYL STANDOFF TUBING
248	PL 7 TRANSFORMER	6036	COLLAR ALLEN WRENCH
249	PL 7 BULB	6037	COLLAR SCREW
250	PL 7 SOCKET	6067	FENDER WASHER
2001	SCOREBOARD PCB	6076	COTTER PIN
2003	BOO BUTTON	6064	BASE TO CABINET BOLT 5/16-18 X 3"
2007	SPEAKER	6706X	OH SENSOR ASSY. W/REED SWITCHES
2008	SOLENOID	6707X	SCORE/EJECT SENSOR ASSY.
SC2070X	MAIN PCBA	6707A	1" REED SWITCH-SCORE/EJECT
2071	TRANSFORMER	6711X	RIBBON CABLE ASSY.
2320	IC EPROM	7001X	GOALIE & BLOCK ASSY. WHITE/BLUE
2368	IC MICROPROCESSOR	7002X	GOALIE & BLOCK ASSY. WHITE/RED
341X	SCOREBOARD ASSEMBLY	7005A	PLAYER (LS/SC) WHITE/RED
342	SCOREBOARD COVER	7007B	PLAYER (LS/SC) WHITE/BLUE
3001X	DOME ASSEMBLY	7008A	PLAYER (SS/SC) WHITE /RED
3002	CHUTE/NET ASSY.	7010B	PLAYER (SS/SC) WHITE/BLUE
3002A	NET CURTAIN	7025B	DECAL (BOO/EJECT) BLACK
3004	NET MOUNT TUBE (LONG)	7030X	CIGARETTE DECAL (SET OF 4)
3005	NET MOUNT TUBE (SHORT)	7118	DECAL (BASE) (NEW STYLE)
3006	GOALIE BLOCK	745	DECAL (CABINET) NEW STYLE (SILVER)
3007	GOALIE TRACK MNT. TUBE	RC60601A	5/32" ALLEN WRENCH
3008	PLAYER LOCK WASHERS	6026	1/4" T HANDLE ALLEN WRENCH
3009	BUMPER STANDOFF	6038	#1 SQUARE DRIVE BIT
3010A	GOALIE KNOB & ROD ONLY	944	SERVICE MANUAL
3010X	GOALIE ROD W / SWING ARM.		
3011	"D" FLECTOR		
3012X	GEARBOX ASSEMBLY		
3013X	PUCK		
3016	ROD BEARING		
3017X	GRIP BUMPER ASSY.		
3018	NET RAMP		
3020	ROD GRIPS		
SK321	PLAYER ROD 1, 5, 6, 10 WINGERS		
SK322	PLAYER ROD 2, 4, 7, 9 DEFENSEMEN		
3024	PLAYER ROD 3, 8 CENTERMEN		

Previous boards and sensors - Photo identification


1st Generation Main PCB




2nd Generation Main PCB



3rd Generation Main PCB




Older version Oh Sensor




Oldest and New Version Oh Sensor
(oldest version was same concept but 3 large reed switches rather than 4 small)


Display Board Revision Identification



2nd Generation Display Board




3rd Generation Display Board



4th Generation Display Board (current)

Scoreboard Assemblies




341X - Scoreboard Assembly

1. 341 – Scoreboard Housing
2. 249P – PL7 Bulb
3. 281XL – Scoreboard harness (long)
4. 281XS – Scoreboard harness (short)
5. 2001X – Scoreboard Interface PCB
6. 342 – Scoreboard Cover
7. 243X – Display PCB


Old Style Scoreboard (parts unavailable)






1001-P700 – Cabinet Assembly & 3001X – Dome Assembly

1. 343A – Shots on Goal Overlay
2. 343B – Home/Away Overlay
3. 7024 – White Sideboard Decal
4. 7027 – Yellow Sideboard Decal
5. 6711X – Ribbon Cable Assembly. (new scoreboard) , 6711XO – Ribbon Cable (old scoreboard)
6. 7008A – Red Player Short Stick (4 per game)
7. 7001X – Blue Goalie & Block Assembly.
8. 3025X – Ice Surface Assembly.
9. 7005A – Red Player Long Stick (1 per game)
10. 1016 – Dome Hinge
11. 745 – Super Chexx Cabinet Decal
12. 7007B – Blue Player Long Stick (1 per game)
13. 3002 – Chute/ Net
14. 7010B – Blue Player Short Stick (4 per game)
15. 7002X – Red Goalie & Block Assembly.




1001-P700 Cabinet Asy. (Solenoid)

1. 4004 – Collar Rubber
2. 3009 – Defenseman Standoff
3. 3035 – Rod Washer
4. 2108X – Solenoid Asy. (new see below for old style)
5. 3013X – Puck Asy.
6. 1019 – Centerman Stop
7. 3024 – Player Rod Centerman (34.5")




2008X – Old Style Chexx/Super Chexx Solenoid



2108X – New Style Super Chexx Solenoid




1002X – Long Rod Collar




1001-p700 Cabinet Asy. (corner):




1. 3017X – Grip Bumper Asy.
2. 2003 – Boo Button
3. SK321 – Player Rod (winger, 39”)
4. 1009X – Player Track 3
5. 1007X – Player Track 1
6. 4003 – Cabinet Gasket
7. 4004 – Collar Rubber
8. 1003X – Rod Collar (short)
9. 3008 – Player Lock Washer (on gearbox)
10. 3012X – Gearbox Asy.
11. 1003X – Rod Collar (short)
12. 1008X – Player Track 2
13. 1019 – Centerman Stop
14. SK321 – Player Rod (winger, 39”)





1001-p700 Cabinet Asy. (goal):

1. SK322 – Player Rod (defenseman, 23.6”)
2. 1009X – Player Track
3. 1018X – Goalie Bearing Asy.
4. 6706X – “OH” Sensor PCB
5. 3010X – Goalie Rod Asy.
6. 6707X – Score/Eject Sensor
7. 1013 – Puck Ramp
8. 3024 – Player Rod (centerman)
9. 1004X – Goalie Track Asy.
10. 5007 – Cabinet Stiffener











279X—Base harness
#SC2027X—Power Cord


#278X-CABINET HARNESS




278X—Cabinet harness



31





341X Scoreboard housing



Contacts at SEGA




Machine Sales

Telephone: +44 (0) 208 391 8090

Fax: +44 (0) 208 391 8099

www.sega-amusements.co.uk



SEGA Spares

Telephone: +44 (0) 208 391 8060

Fax: +44 (0) 208 391 8096

www.segatotsolutions.com

Customer Services

Telephone: +44 (0) 208 391 8065

Fax: +44 (0) 208 391 8096