ADJUSTMENT ON GAME PC BOARD (EURO CHAMP G25 00679A)

3P CONNECTOR

1	COIN 3
2	3P SELECT
3	3P LEFT
4	3P RIGHT
5	3P UP
6	3P DOWN
7	3P A-BUTTON
8	3P B-BUTTON
9	
10	
11	SERVICE
12	COIN METER 3
13	LOCKOUT 3
14	GND
15	GND

4P CONNECTOR

1	COIN 4
2	4P SELECT
3	4P LEFT
4	4P RIGHT
5	4P UP
6	4P DOWN
7	4P A-BUTTON
8	4P B-BUTTON
9	
10	
11	
12	COIN METER 4
13	LOCKOUT 4
14	GND
15	GND

G-CONNECTOR (JAMMA)

SOLDER SIDE			COMPONENTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
-5V	E	5	-5V
+12V	F	6	+12V
POST	H	7	POST
COIN METER 2	J	8	COIN METER 1
COIN LOCKOUT 2	K	9	COIN LOCKOUT 1
SPEAKER (-)	L	10	SPEAKER (+)
SOUND GND	M	11	SOUND
VIDEO G	N	12	VIDEO R
VIDEO SYNC	P	13	VIDEO B
SERVICE SW	R	14	VIDEO GND
TILT SW	S	15	
COIN 2	T	16	COIN 1
2P SELECT	U	17	1P SELECT
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P A-BUTTON	Z	22	1P A-BUTTON
2P B-BUTTON	a	23	1P B-BUTTON
	b	24	
	c	25	
GND	e	27	GND
GND	f	28	GND

M2 CONNECTOR

1	VIDEO-RED
2	VIDEO-GREEN
3	VIDEO-BLUE
4	VIDEO-SYNC
5	VIDEO-GND

S-CONNECTOR

1	SOUND (+)
2	SOUND (-)
3	

3P CONNECTOR ↓   ↓ G-CONNECTOR

← 4P CONNECTOR

← M2 CONNECTOR   S-CONNECTOR ↑

B

DIP SW A

SOUND VR

INCREASE ⊕

☆ CONTROL OF THIS GAME USES ONE 8-WAY JOYSTICK
   AND TWO BUTTONS.

NOTE) BEFORE CHANGING THE SETTING OF DIP SWITCH,
   TURN THE POWER OFF.

◇ SETTING OF DIP SWITCH-A   (*):FACTORY SETTING

SETTINGS		POSITIONS	1	2	3	4	5	6	7	8
GAME OVER-TYPE IN VS GAME	*	BOTH TEAMS' GAME ARE OVER	OFF							
		LOST TEAM'S GAME IS OVER	ON							
SCREEN ROTATION	*	NORMAL		OFF						
		REVERSE		ON						
TEST MODE	*	NORMAL GAME			OFF					
		TEST MODE			ON					
ATTRACT SOUND	*	WITH				OFF				
		WITHOUT				ON				
PLAY PRICING COIN A	*	1 COIN 1 PLAY					OFF	OFF		
		2 COINS 1 PLAY					ON			
		3 COINS 1 PLAY					OFF	ON		
		4 COINS 1 PLAY					ON			
PLAY PRICING COIN B	*	1 COIN 2 PLAYS							OFF	OFF
		1 COIN 3 PLAYS							ON	
		1 COIN 4 PLAYS							OFF	ON
		1 COIN 6 PLAYS							ON	

◇ SETTING OF DIP SWITCH-B

| SETTINGS		POSITIONS	1	2	3	4	5	6	7	8
GAME DIFFICULTY EASY (A) → DIFFICULT (D)	*	RANK B	OFF	OFF						
		RANK A	ON	OFF						
		RANK C	OFF	ON						
		RANK D	ON	ON						
LENGTH OF PERIOD	*	2 MIN.			OFF	OFF				
		3 MIN.			ON	OFF				
		2.5 MIN.			OFF	ON				
		1.5 MIN.			ON	ON				
GAME TYPE	*	2P GAME					OFF	OFF		
		4 SLOTS 4P GAME					ON	OFF		
		2P GAME × 2					OFF	ON		
		2 SLOTS 4P GAME					ON	ON		
CONTINUE	*	WITH							OFF	
		WITHOUT							ON	

EURO CHAMP '92

© TAITO CORP. 1992

8-WAY JOYSTICK   A-BUTTON   B-BUTTON

|	DEFENSE	OFFENSE
A-BUTTON	SHOOT	SLIDING
B-BUTTON	PASS	ROUGH PLAY (PUNCH, KICK, etc.)

SUPER TECHNIQUES

CYHOLDING

USE THIS FOR AVOIDING AUTO-MATICALLY OPPONENTS SLIDING!!

SEQUENTIAL TRAPPING

KEEP THE A-BUTTON PRESSED WITHOUT TURNING THE JOYSTICK!!

HEEL KICKING

PRESS THE B-BUTTON IN FRONT OF AN OPPONENT!!

BACK HEEL PASSING

TURN THE JOYSTICK TO THE RIVERSE DIRECTION AND PRESS THE B-BUTTON!!

VARIOUS KINDS OF SHOOTINGS

IT CHANGES DEPENDING OF THE TURNING DIRECTION OF THE JOY-STICK! MAKE SURE OF THE OTHER SHOOTING BY YOURSELF!!

OVER HEAD KICKING

SHOOT THE BALL TO THE BACK DIRECTION!!

JUMPING VOLLEY

DIRECTLY VOLLEY-KICK, WHILE JUMPING HORIZONTALLY!!

SELECTION METHOD WHEN A MULTI-PLAYER GAME IS PLAYED

★WHEN SELECTING DIFFERENT NATIONAL FLAGS,
    A PLAYER-AGAINST-PLAYER GAME CAN BE PLAYED!

★WHEN SELECTING A SAME NATIONAL FLAG,
    A COMPETING-AGAINST-COMPUTER GAME CAN BE PLAYED!

TAITO
TAITO CORPORATION

G35 00446A