CHOKY CHOKY

SWITCH 1.		1	2	3	4	5	6	7	8
NUMBER OF BALL	4 EA	OFF	OFF						
	5 EA	ON	OFF						
	6 EA	OFF	ON						
	3 EA	ON	ON						
TIME	60 SEC			OFF					
	90 SEC			ON					
ENERGY DECREASE	NORMAL				OFF	OFF			
	BIG				ON	OFF			
	SMALL				OFF	ON			
	VERY SMALL				ON	ON			
BALL SPEED	NORMAL						OFF	OFF	
	FAST						ON	OFF	
	VERY FAST						OFF	ON	
	SLOW						ON	ON	
GAME MATCH	3 TIMES MATCH								OFF
	2 TIMES MATCH								ON

SWITCH 2.		1	2	3	4	5	6	7	8
DEMO SOUND	YES	OFF							
	NO	ON							
KOREAN / ENGLISH	KOREAN		OFF						
	ENGLISH		ON						
CREDIT	1 : 1			OFF	OFF	OFF			
	1 : 2			ON	OFF	OFF			
	2 : 3			OFF	ON	OFF			
	1 : 3			ON	ON	OFF			
	2 : 1			OFF	OFF	ON			
	3 : 1			ON	OFF	ON			
	4 : 1			OFF	ON	ON			
	5 : 1			ON	ON	ON			
DIFFICULTY	NORMAL						OFF	OFF	
	DIFFICULTY						ON	OFF	
	VERY DIFFICULTY						OFF	ON	
	EASY						ON	ON	
START MODE	GAME MODE								OFF
	TEST MODE								ON