

DOG FIGHT

SOLDER SIDE		PARTS SIDE	
SIGNAL NAME	PIN No.	SIGNAL NAME	PIN No.
-5V	A 1	+12V	B 1
SPEAKER	A 2	SPEAKER	B 2
1P SHOOT 2	A 3	1P UP	B 3
1P RIGHT	A 4	1P LEFT	B 4
1P START	A 5	2P START	B 5
2P SHOOT 2	A 6	2P UP	B 6
2P DOWN	A 7		B 7
2P LEFT	A 8	2P RIGHT	B 8
COIN COUNTER 1	A 9	1P DOWN	B 9
COIN 2	A10	COIN 1	B10
	A11	COIN COUNTER 2	B11
1P SHOOT 3	A12	2P SHOOT 3	B12
VIDEO GREEN	A13	VIDEO BLUE	B13
VIDEO RED	A14	VIDEO SYNC	B14
1P SHOOT 1	A15	2P SHOOT 1	B15
GND	A16	GND	B16
GND	A17	GND	B17
+5V	A18	+5V	B18

DIP SWITCH 1

1	2	3	4	5	6	7	8	
OFF (DON'T USE)	OFF (DON'T USE)					OFF (DON'T USE)		● Coin-A
		OFF	OFF				1 Coin - 1 Credit	
		ON	OFF				1 Coin - 2 Credit	
		OFF	ON				1 Coin - 3 Credit	
		ON	ON				2 Coin - 1 Credit	
							● Coin-B	
					OFF		OFF	1 Coin - 1 Credit
					ON		OFF	1 Coin - 2 Credit
					OFF		ON	1 Coin - 3 Credit
					ON		ON	2 Coin - 1 Credit
					● TV-Screen			
					OFF	Normal		
					ON	Invert		

DIP SWITCH 2

1	2	3	4	5	6	7	8	
				OFF (DON'T USE)	OFF (DON'T USE)			Number of Character
OFF						3		
ON						5		
						Degree of Difficulty		
	OFF					Normal		
	ON					Difficult		
						● Sound for Demonstration		
		OFF				Not sound		
		ON				Sound		
			OFF			● Continue Game		
			ON	Enable				
				Disable				
				● TV-Screen				
				OFF	Table type use			
				ON	Up-right type use			
					● Control Panel			
					OFF	Table type use		
					ON	Up-right type use		

change both together