

# IMPORTANT

Two model types of Toshiba Projection Monitor are used on the CRISIS ZONE DX.

The only visible difference is the Video Input Connection.

Model P503SG1 uses BNC connectors and Model P503SG2 uses a 15way mini 'D' Connector.

All Crisis Zone DX games have BNC connectors fitted to the Video Loom coming from the Joint Box.

When model P503SG2 is used, a "Toshiba BNC to D Adaptor Loom", (Part No 69200080), must be fitted. *(This adaptor loom should remain with the projection monitor if it is returned at any time for repair or exchange).*

