






● OVERVIEW


- PCB CONNECTOR : JAMMA STANDARD
- CRT MONITOR : LANDSCAPESCREEN
- ARRANGING CONTROL PANNEL



BUTTON 1




BUTTON 2



BUTTON 3

- BUTTON 1GUN SHOOT BUTTON
- BUTTON 2MISSILE SHOOT BUTTON
- BUTTON 3THUNDER BUTTON

● DIP SW POSITION



JAMMA STANDARD

SOLDERING SIDE				COMPONENT SIDE
GND	A	1	GND	
GND	B	2	GND	
+5V	C	3	+5V	
+5V	D	4	+5V	
N.C.	E	5	N.C.	
+12V	F	6	+12V	
	H	7		
COIN COUNTER2	J	8	COIN COUNTER 1	
COIN LOCK OUT2	K	9	COIN LOCK OUT1	
SP (-)	L	10	SP (+)	
N.C.	M	11	N.C.	
VIDEO GREEN	N	12	VIDEO RED	
VIDEO SYNC	P	13	VIDEO BLUE	
SERVICE SW	R	14	VIDEO GND	
N.C.	S	15	N.C.	
COIN SW 2	T	16	COIN SW 1	
START SW 2	U	17	START SW 1	
2P CONTROL UP	V	18	1P CONTROL UP	
2P CONTROL DOWN	W	19	1P CONTROL DOWN	
2P CONTROL LEFT	X	20	1P CONTROL LEF	
2P CONTROL RIGHT	Y	21	1P CONTROL RIGHT	
2P CONTROL PUSH1	Z	22	1P CONTROL PUSH1	
2P CONTROL PUSH2	a	23	1P CONTROL PUSH2	
2P CONTROL PUSH3	b	24	1P CONTROL PUSH3	
N.C.	c	25	N.C.	
N.C.	d	26	N.C.	
GND	e	27	GND	
GND	f	28	GND	

● CONNECTOR TYPE

CR7-56DA-3.96 : HIROSE
 1168-056-009 : KEL

「TURTLE SHIP」 DIP SWITCH INDEX

DIP sw 1

CONTENTS		1	2	3	4	5	6	7	8
1	PLAYER / 1 CREDIT	OFF	OFF	OFF					
2	/ 1	ON	OFF	OFF					
3	/ 1	OFF	ON	OFF					
4	/ 1	ON	ON	OFF					
5	/ 1	OFF	OFF	ON					
6	/ 1	ON	OFF	ON					
7	/ 1	OFF	ON	ON					
8	/ 1	ON	ON	ON					
NORMAL MODE DIFFICULT MODE					OFF ON				
NORMAL SCREEN REVERSE SCREEN						OFF ON			
NOT USED							OFF ON		
DICONTINUE MODE CONTINUE MODE								OFF ON	
NORMAL PLAY TEST PLAY									OFF ON

DIP sw 2

CONTENTS		1	2	3	4	5	6	7	8
1	CREDIT / 1 COIN	OFF	OFF	OFF					
2	/ 1	ON	OFF	OFF					
3	/ 1	OFF	ON	OFF					
4	/ 1	ON	ON	OFF					
1	COIN / 1 CREDIT	OFF	OFF	ON					
2	/ 1	ON	OFF	ON					
3	/ 1	OFF	ON	ON					
4	/ 1	ON	ON	ON					
NO MUSIC IN DEMO					OFF ON				
BONUS PLAYER	ONLY 150,000					OFF	OFF		
	EVERY 150,000					ON	OFF		
	ONLY 200,000					OFF	ON		
	EVERY 200,000					ON	ON		
NOT USED								OFF ON	
NORMAL MODE TEST MODE									OFF ON



PhilKo

PhilKo Corporation

ADD: 10, 3-KA, JONGRO, JONGRO-GU,
SEOUL, KOREA

TELEX: PHILKO K29617

FACSIMILE: (02) 274-2846

TEL: (02) 741-0101 / 744-1128