

**Post Adjustment**

C - Conservative  
M - Medium  
L - Liberal

**RUBBER RINGS**

- |               |               |
|---------------|---------------|
| R1-7A-121     | R6-7A-120-250 |
| R2-7A-131     | R7-7A-120-400 |
| R3-7A-120-031 |               |
| R4-7A-120-100 |               |
| R5-7A-120-125 |               |

**BALL GUIDES & WIRE FORMS**

- |           |           |
|-----------|-----------|
| W1-6A-101 | W7-A-383  |
| W2-6A-235 | W8-A-581  |
| W3-6A-236 | W9-A-589  |
| W4-6A-237 | W10-A-590 |
| W5-6A-238 | W11-A-591 |
| W6-A-149  |           |

**PLASTIC SHIELDS**

TOP ARCH SET 13C-112-1R & 1LA  
PLAYFIELD SET 13A-112-2 TO-7  
(P-2 TO P-7)

**MISCELLANEOUS PARTS**

1. 5-BANK TARGET D-580-5A
2. SPIN TARGET A-563-7
3. THUMPER CAP 13A-29
4. ROLL-OVER BUTTON 4B-275
5. FLIPPER & SHAFT A-193
6. BALL GATE, LEFT A-104-L
7. BALL GATE, RIGHT A-104-R
8. ROLL-OVER BUTTON ASS'Y A-593
9. TARGET ASS'Y A-461-1
10. TOP ARCH RAIL 6B-222
11. INSTRUCTION PLATE 14B-3-1
12. SHOOTER GAUGE 14A-2-4
13. BIG FLIPPER 4B-265




FIGURE 10. HOT HAND PLAYFIELD PARTS