

# JOIN'EM EDGE CONNECTOR ASSIGNMENT

## CONNECTOR (4mmPITCH 44PINS)

SOLDERED SIDE		PARTS MOUNTED SIDE	
#		#	
1	GROUND	2	GROUND
3	+ 5 V	4	+ 5 V
5	- 5 V	6	+12V
7	SPEAKER	8	SPEAKER
9	1 PLAYER-UP	10	2 PLAYER-UP
11	1 PLAYER-DOWN	12	2 PLAYER-DOWN
13	1 PLAYER-RIGHT	14	2 PLAYER-RIGHT
15	1 PLAYER-LEFT	16	2 PLAYER-LEFT
17		18	
19		20	
21		22	
23		24	
25	COIN 1	26	
27	COIN 2	28	
29	1 PLAYER START	30	VIDEO-RED
31	2 PLAYER START	32	VIDEO-GREEN
33		34	VIDEO-BLUE
35		36	VIDEO-SYNC
37		38	GROUND
39		40	
41	+ 5 V	42	+ 5 V
43	GROUND	44	GROUND

## PC BOARD EDGE CONNECTOR ASSIGNMENT

CONNECTOR MUST  
BE SET FROM THIS  
DIRECTION  
↓

