B :	L	0	O	D	В	R	O	S
							-	

DIPSW-1				1	2	3	4	5	6	7	8
COIN MODE SELECT COIN MODE 1			COIN MODE 1	0FF							
			COIN MODE 2	ON							
			1 COIN 1 CREDIT	OFF	OFF	OFF	0FF	OFF			
			2 COINS 1 CREDIT	1	ON	0FF	0FF	0FF			
			3 COINS 1 CREDIT	'	OFF	ON	OFF	OFF			
			4 COINS 1 CREDIT		ON	ON	0FF	0FF			
			5 COINS 1 CREDIT		OFF	OFF	ON	0FF			
	MODE 1		6 COINS 1 CREDIT		ON	0FF	ON	OFF			
			1 COIN 2 CREDITS		OFF	ON	ON	OFF			
			1 COIN 3 CREDITS		ON	ON	ON	OFF			
			1 COIN 4 CREDITS		0FF	0FF	OFF	ON			
C			1 COIN 5 CREDITS		ON	0FF	OFF	ON			
0			1 COIN 6 CREDITS		OFF	ON	OFF	ON			
I			2 COINS 3 CREDITS		ON	ON	OFF	ON			
N	M ·		3 COINS 2 CREDITS		OFF	OFF	ON	ON			
			5 COINS 3 CREDITS		ON	0FF	ON	ON			
M			8 COINS 3 CREDITS		OFF	ON	ON	ON			ļ
0			FREE PLAY	OFF	ON	ON	ON	ON			<u> </u>
D		COIN A	1 COIN 1 CREDIT	ON	OFF	0FF					<u>.</u>
E		:	2 COINS 1 CREDIT	1	ON	OFF					
		2 COIN B	3 COINS 1 CREDIT]	OFF	ON	.,.,				<u>.</u>
			5 COINS 1 CREDIT		ON	ON				- <i></i>	
	MODE 2		1 COIN 2 CREDITS				OFF	OFF			
			1 COIN 3 CREDITS				ON	0FF			
			1 COIN 5 CREDITS				OFF	ON			ļ
_			1 COIN 6 CREDITS	ON			ON	ON			
STARTING COIN			NORMAL						0FF		
			x 2						ON		
										,	
NOT IN USE											
				1							

DIP SWITCH SETTING 2

DIPSW-2		1	2	3	4	5	6	7	8
	3	OFF	OFF						
No. of LIVES	2	ON	0FF						
	5	OFF	ON		. ,				
	1	ON	ON						
	100000, +200000 EVERY			OFF	OFF				L
EXTEND PLAY	200000, +300000 EVERY			ON	OFF				İ
(extend-every)	500000 ONLY			OFF	ON				
	NO EXTENDED			ON	ON				
	1 (NORMAL)					OFF	OFF		
DIFFICULTY	2(EASY)					ON	OFF		
	3(HARD)					OFF	ON		
	4(HARDEST)					ON	ON		
CONTINUE PLAY	YES							0FF	
V	NO			<u> </u>				ON	
DEMO SOUND	YES								OFF
and the second s	NO			<u> </u>					ON

AT POWER ON. IF YOU TOUCH THE JOYSTICK, YOU WILL HAVE DIP-SW SETTING ON THE SCREEN.


半田面	端子番号	部品面
SOLDER SIDE	Pin No.	PARTS SIDE
G N D	A 1	G N D
G N D	B 2	G N D
+ 5 V + 5 V	D 4	+5 V +5 V
-5 V	E 5	-5 V
+12 V	F 6	+1 2 V
誤挿入防止キー	H 7	誤挿入防止キー
COIN COUNTER 2	J 8	COIN COUNTER 1
N. C.	K 9	N. C.
SP (-)	L 10	SP (+)
VIDEO GREEN	M 11 N 12	N. C. VIDEO RED
VIDEO SYNC SERVICE SW	P 13 R 14 S 15 T 16	VIDEO BLUE VIDEO GND
N. C.	S 15	N. C.
COIN SW 2	T 16	COIN SW I
START SW 2	U 17	START SW 1
2P CONTROL UP	V 18	1P CONTROL UP
2P CONTROL DOWN	W 19	1P CONTROL DOWN
2 P CONTROL UP 2 P CONTROL DOWN 2 P CONTROL LEFT 2 P CONTROL RIGHT	X 20	1 P CONTROL LEFT
12P CONTROL PUSH 1	Z 22	IP CONTROL PUSH 1
2 P CONTROL PUSH 2	a 23	IP CONTROL PUSII 2
2 P CONTROL PUSH 3	b 24	IP CONTROL PUSII 3
N. C.	c 25	N. C.
N. Č.	d 26	N. C.
GND	e 27	GND
GND	f 28	GND

How to play:

BLOOD BROS. is a simultaneous two player game.

One 8-way joystick and 3 buttons for each player.

- 1. Use joystick for player and cursor control.
- 2. Use button (A) for firing.
- 3. Use button (B) for rolling to left or right.
- 4. Use button (C) for throwing dynamite.
- 5. Damage gauge: to clear each scene, you want to put out red damage gauge by shooting the enemy.






Increase in number of dynamite



Destruction power up



Machine gun (fast firing)

Insert extra coins to continue game.