

BRAIN GAME



GAME FEATURES

- TWO PLAYER INTERACTIVE. PLAYERS CAN JOIN IN AT ANY TIME
- GAME CONTINUATION BUY-IN FEATURE.

TOFFY EDGE CONNECTOR



SOLDER SIDE	NO.	NO.	PARTS SIDE		
GND	A	1	GND		
GND	• В	2	GND		
+5V	С	3	+5V		
+5V	D	4	+5V		
	E	5			
+12V	F	6	+12V		
	Н	7			
	J	8			
GND	K	9	GND		
SPEAKER (-)	L	10	SPEAKER (+)		
AUDIO GND	M	11			
VIDEO GREEN	N	12	VIDEO RED		
VIDEO SYNC	P	13	VIDEO BLUE		
	R	.14	VIDEO GND		
	S	15			
COIN SW 2	T	16	COIN SW 1		
2P START	U	17	1P START		
2P UP	V	18	1P UP		
2P DOWN	W	19	1P DOWN		
2P LEFT	X	20	1P LEFT		
2P RIGHT	Y	21	1P RIGHT		
2P SW A BUTTON	Z	22	IP SW A BUTTON		
2P SW B BUTTON	a	23	IP SW B BUTTON		
2P SW C BUTTON	b	24	IP SW C BUTTON		
	c	25			
	d	- 26			
GND	e	27	GND		
GND	f	28	GND		

JOYSTICK LEVER

1	В	†	В			
← 📵 →	0	← 🔘 →	0			
.†	AO OC	ţ	AO O C			

POWER SOURCE

+5V	5/
+12A	1

DIP SWITCH

DIP :	SWITCH 1	1	2	- 3	4	5	6	7	8
COIN/CREDIT COIN I	ICOIN IPLAY					ON	ON	ON	ON
	1COIN 2PLAY					ON	OFF	ON	ON
	1COIN 5 PLAY					OFF	ON	ON	ON
	ICOIN 6PLAY					OFF	OFF	ON	ON
	2COIN 1PLAY					ON	ON	ON	OFF
	3COIN 1PLAY					ON	ON	OFF	ON
	4COIN 1PLAY		7		77	ON	ON	OFF	OFF
	4COIN 2PLAY			4		ON	OFF	OFF	OFF
COIN/CREDIT COIN 2	1COIN 1PLAY	ON	ON	ON	ON				
	ICOIN 2PLAY	ON	OFF	ON	ON				
	ICOIN 5PLAY	OFF	ON	ON	ON				
	ICOIN 6 PLAY	OFF	OFF	ON	ON				
	2COIN IPLAY	ON	ON	ON	OFF				
	3COIN IPLAY	ON	ON	OFF	ON				
	4COIN IPLAY	ON	ON	OFF	OFF				
	4COIN 2PLAY	ON	OFF	OFF	OFF				

DIF	SWITCH 2	1	2	3	4	5	6	7	8
DIFFICULTY -	NORMAL	ON	OFF						
	EASY	ON	ON						
	DIFFICULT	OFF	ON						
	VERY DIFFICULT	OFF	OFF						
EXTRA PLAYER	30,000 / 50,000 / 100,000			ON	OFF				
	50,000 / 100,000			OFF	ON				
	100,000 / 200,000			ON	ON				
	NO EXTRA			OFF	OFF				
	2							ON	ON
NUMBER OF PLAYER	3							ON	OFF
	4			## ##				OFF	ON
	5	#						OFF	OFF

