

MANUAL



CAPCOM

SETTING EXPLANATION


OPCB CONNECTOR

JAMMA STANDARD

OCRT MONITOR

VERTICAL SCREEN

OCONTROL PANEL





08-WAY LEVER: MOVES PLAYER IN 8 DIRECTIONS

OSHOT BUTTON: NORMAL SHOT

○BOMB BUTTON: BOMB

ODIP SW (THERE ARE TWO TYPES OF PCB.)





JAMMA STANDARD

SOLDER SIDE			COMPONENTS SIDE
GND	A	1	GND
GND	В	2	GND
+5V	С	3	+5V
+5V	D	4	+5V
N.C.	Е	5	N.C.
+12V	F	6	+12V
	Н	7	
N.C.	J	8	COIN COUNTER 1
(COIN LOCK OUT 2)	K	9	(COIN LOCK OUT 1)
SP (-)	L	10	SP (+)
N.C.	M	11	N.C.
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	Р	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
N.C.	S	15	TEST SW
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
${}^{2\mathrm{P}}$ SHOT 1 ${}^{_{(2\mathrm{P}}}$ SHOT)	Z	22	1P SHOT 1 (1P SHOT)
${}^{2\mathrm{P}}$ SHOT 2 ${}^{(2\mathrm{P}\;\mathrm{BOMB})}$	a	23	1P SHOT 2 (1P BOMB)
N.C.	b	24	N.C.
N.C.	c	25	N.C.
N.C.	d	26	N.C.
GND	e	27	GND
GND	f	28	GND

• PARTS NAME

CR7E-56DA-3.96E: (HIROSE)

OR

1168-056-009 :(KEL)

●DIP SW(A)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
	1 COIN 1 CREDIT	OFF	OFF	OFF					
	1 COIN 2 CREDITS	ON	OFF	OFF					
	1 COIN 3 CREDITS	OFF	ON	OFF					
COIN 1	1 COIN 4 CREDITS	ON	ON	OFF					
SETTINGS	1 COIN 6 CREDITS	OFF	OFF	ON					
	2 COINS 1 CREDIT	ON	OFF	ON					
	3 COINS 1 CREDIT	OFF	ON	ON					
	4 COINS 1 CREDIT	ON	ON	ON					
	1 COIN 1 CREDIT				OFF	OFF	OFF		
	1 COIN 2 CREDITS				ON	OFF	OFF		
	1 COIN 3 CREDITS				OFF	ON	OFF		
COIN 2	1 COIN 4 CREDITS				ON	ON	OFF		
SETTINGS	1 COIN 6 CREDITS]			OFF	OFF	ON		
	2 COINS 1 CREDIT				ON	OFF	ON		
	3 COINS 1 CREDIT				OFF	ON	ON		
	4 COINS 1 CREDIT				ON	ON	ON		
CONTINUE	NORMAL							OFF	
COIN	CONTINUE COIN							ON	
NOT USED									OFF

 $[\]rm \%IF$ CONTINUE COIN MODE IS "ON", GAME STARTS WITH 2-COIN 1-CREDIT AND CONTINUES WITH 1-COIN 1-CREDIT.

●DIP SW(B)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
DIFFICULTY	EASY	OFF	OFF	OFF					
		ON	OFF	OFF					
		OFF	ON	OFF					
	NORMAL	ON	ON	OFF					
LEVEL		OFF	OFF	ON			-		
		ON	OFF	ON					
	•	OFF	ON	ON					
	HARD	ON	ON	ON					
EXTENDED	1ST 600000Pts.				OFF OFF	OFF			
	EVERY 1400000Pts.					OFF			
	1ST 600000Pts.	1							
	2ND 2000000Pts.				ON	OFF			
PLAY	3RD 4500000Pts.								
	1ST 1200000Pts.				OPE	ON			
	2ND 3500000Pts.				OFF	ON			
	ONLY 2000000Pts.				ON	ON			
NOT USED			***************************************				OFF	OFF	OFF

●DIP SW(C)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
THE NUMBER	3 PLAYERS	OFF	OFF						
THE NUMBER OF	1 PLAYER	ON	OFF						
	2 PLAYERS	OFF	ON						
PLAYER	4 PLAYERS	ON	ON						
EDEE DI AV	NORMAL			OFF					
FREE PLAY	FREE PLAY			ON					
SCREEN	NO				OFF				
PAUSE	YES				ON			_	
SCREEN	NO				•	OFF			
FLIP	YES					ON			
DEMON-	NO						OFF		
STRATION SOUND	YES						ON		
CONTINUE	NO							OFF	
	YES							ON	
TEST MODE	GAME MODE								OFF
	TEST MODE	7							ON

**HIGHLIGHTED CHARACTER INDICATES FACTORY SETTING.

TEL (06) 946-2058 FAX NO. (06) 946-6657

^{**}MAKE SURE THE POWER IS OFF BEFORE CHANGING DIP SWITCHES.