

## DOUBLE DRAGON II

DIPSW-1		1	2	3	4	5	6	7	8	
COIN 1	1 COIN 1 PLAY	OFF	OFF	OFF						
	1 COIN 2 PLAY	ON	OFF	OFF						
	1 COIN 3 PLAY	OFF	ON	OFF						
	1 COIN 4 PLAY	ON	ON	OFF						
	1 COIN 5 PLAY	OFF	OFF	ON						
	2 COIN 1 PLAY	ON	OFF	ON						
	3 COIN 1 PLAY	OFF	ON	ON						
	4 COIN 1 PLAY	ON	ON	ON						
COIN 2	1 COIN 1 PLAY				OFF	OFF	OFF			
	1 COIN 2 PLAY				ON	OFF	OFF			
	1 COIN 3 PLAY				OFF	ON	OFF			
	1 COIN 4 PLAY				ON	ON	OFF			
	1 COIN 5 PLAY				OFF	OFF	ON			
	2 COIN 1 PLAY				ON	OFF	ON			
	3 COIN 1 PLAY				OFF	ON	ON			
	4 COIN 1 PLAY				ON	ON	ON			
SCREEN INVERT	INVERT NORMAL							OFF ON		
DIPSW-2		1	2	3	4	5	6	7	8	
DIFFICULTY NORMAL		OFF	OFF							
EASY		OFF	ON							
LESS THAN DIFFICULTY		ON	OFF							
DIFFICULTY		ON	ON							
BONUS:										
30,000 EVERY 60,000					OFF	OFF				
40,000 EVERY 80,000					ON	OFF				
20,000 ONLY					OFF	ON				
40,000 ONLY					ON	ON				
NUMBER	1							OFF	OFF	
OF	2							ON	OFF	
PLAYERS	3							OFF	ON	
	4							ON	ON	

SOLDIER SIDE		PARTS SIDE
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
-5V	5	-5V
+12V	6	+12V
	7	
COIN COUNTER2	8	COIN COUNTER2
	9	
SP ( - )	10	SP ( + )
	11	
VIDEO GREEN	12	VIDEO RED
VIDEO SYNC	13	VIDEO BLUE
SERVICE	14	VIDEO GND
	15	
COIN 2	16	COIN 1
2P START	17	1P START
2P UP	18	1P UP
2P DOWN	19	1P DOWN
2P LEFT	20	1P LEFT
2P RIGHT	21	1P RIGHT
SH SW 1 (KICK)	22	1P PUSH SW 1 (KICK)
SH SW 2 (JUMP)	23	1P PUSH SW2 (JUMP)
SH SW3 (PUNCH)	24	1P PUSH SW3 (PUNCH)
	25	
	26	
GND	27	GND
GND	28	GND