

This document has been downloaded from:



The largest resource for amusement machines
documentation on the world wide web!



FLIPPERSPILL.COM

SETTING UP THE SOFT DIP ON THE MULTI VIDEO SYSTEM

1. TURN POWER ON.
2. PUSH THE TEST BUTTON INSIDE THE CABINET.
3. THE FOLLOWING SCREEN WILL APPEAR.

MOVE LEFT JOYSTICK UP/DOWN TO MOVE THE POINTER TO "SETTING UP THE SOFT DIP". PRESS "A" BUTTON TO SET.

HARDWARE TEST
SETTING UP THE HARD DIP
SETTING UP THE SOFT DIP
BOOKKEEPING
SETTING UP THE CODE NUMBER
SETTING UP THE CALENDAR
EXIT

THE FOLLOWING SCREEN WILL BE DISPLAYED:

CABINET SET UP
SLOT 1 (GAME TITLE)
SLOT 2 (GAME TITLE)
SLOT 3 (GAME TITLE)
SLOT 4 (GAME TITLE)
SLOT 5 (GAME TITLE)
SLOT 6 (GAME TITLE)

4. SELECT THE GAME TITLE YOU WANT AND PRESS "A" BUTTON TO VIEW THE SOFT DIP SETTING OF EACH INDIVIDUAL GAME.

■ NEO TURF MASTERS SOFT DIP SETTINGS ■

Page 1 Initial Settings Screen

NEO TURF MASTERS	
▶ TIME	00m 30 s
HOLE(1st)	3
HOLE(continue)	3
MATCH PLAY HOLE	WIN + / LOS -
CONTINUE	ON
DIFFICULTY	LEVEL 4
▼NEXT PAGE	

Page 2 Initial Settings

NEO TURF MASTERS	
▶ PLAY MANUAL	ON
DEMO SOUND	WITH
CREDIT/LEVEL	ON/ON
LANGUAGE	ENGLISH

- How to operate: ① Use the Joystick to move cursor up or down to items you want to change.
 ② Press A Button to proceed to new settings and set selections.
 (Press B Button to return to previous settings.)

[TIME] Set the time allowed per shot.
Factory Setting: 30 seconds (1 second - 29 minutes 59 seconds possible.)
[HOLE(1st)] Set the number of holes for the first 1 credit.
Factory Setting: 3 Holes/credit (1 hole/credit - 99 holes/credit possible.)
[HOLE(continue)] Select the number of holes per continue.
Factory Setting: 3 Holes/continue (1 hole/continue - 15 holes/continue possible.)
[HOLE PENALTY] Select penalty per hole.
Bogey → Per → Give Up → No Penalty
[MATCH PLAY HOLE] Set the 1 hole gain or loss for winning or losing in 2 player match play.
WIN +/LOS - → WIN 0/LOS 0 → WIN 0/LOS - → WIN +/LOS 0
[CONTINUE] Set the Continue Play option.
ON → OFF
[DIFFICULTY] Set the game's difficulty level.
Factory Setting: 4 (1-8 possible.)
[PLAY MANUAL] Turn on or off the play instructions.
ON → OFF
[DEMO SOUND] Set sound during demonstration screens.
WITH → WITHOUT
[CREDIT / LEVEL DISPLAY] Set credit and level display.
ON/ON → ON/OFF → OFF/ON → OFF/OFF
[LANGUAGE] Change language. (Only for Europe or Asia.)
ENGLISH → SPANISH → PORTUGUESE