HATCH CATCH

DIP SW 1									
		1	2	3	4	5	6	7	8
DEMO SOUND	NO YES	Off On							
COIN : CREDIT	1 : 1 1 : 2 2 : 3 1 : 3 2 : 1 3 : 1 4 : 1 5 : 1			Off On Off On Off On Off On	Off Off On On Off Off On On	Off Off Off Off On On On On			
DIFFICULTY	NORMAL HARD HARDEST EASY						Off On Off On	Off Off On On	
START MODE	GAME MODE TEST MODE								Off On