




TIME WARNER
INTERACTIVE™



Troubleshooting Guns Installed with Kits

Supplement to the Area 51 Universal Kit Installation Instructions (TM-405, 1st printing)

THIS SUPPLEMENT sheet describes how to troubleshoot the guns included with this universal kit. If you are having problems with the guns tracking across the whole screen, check these items before calling Customer Service.

- ① Check the brightness and contrast. Adjust the picture as bright and with as much contrast as you can. (However, do not boost the brightness to the point where the screen is washed out and you can see the diagonal retrace lines.)
- ② Check that you have a pure white screen in the monitor purity test (under Monitor Tests in the self-test procedure). Follow the instructions on page 2-7

of the *Area 51 Universal Kit Installation Instructions*.

- ③ Make sure the monitor screen is clean and free of dust.

When the monitor is properly adjusted, the guns should track to within *two inches* of the left side of the screen and *all the way* to the right side. If you still have problems after checking these three items, call Customer Service at the number on the back of this sheet. We suggest you keep this supplement with your kit manual, and refer to it when installing the guns.



If you need technical assistance, call your distributor or
Time Warner Interactive Customer Service at one of the following locations:

United States: (408) 434-3950

Time Warner Interactive/Atari Games Corporation,
737 Sycamore Drive
Milpitas, CA 95035
(Monday–Friday, 7:30 a.m.– 4:00 p.m. Pacific time)

OR

Europe: 062-52155

Atari Games Ireland Limited,
Tipperary Town, Ireland
(Monday–Friday, 9:00 a.m.–5:30 GMT)